


SUCTION CUPS 진공패드

SOLVAC

Suction cupsS MU2 - MU15


(ONLY RUBBER)

MU2, MU4, MU6, MU8




(FITTING)

M5-2




(Suction cup with fitting)



VACUUM PAD	$\varnothing A$	$\varnothing B$	$\varnothing C$	L3
MU 2	$\varnothing 2.2$	$\varnothing 2.6$	$\varnothing 7$	0.8
MU 4	$\varnothing 4$	$\varnothing 4.6$		
MU 6	$\varnothing 6$	$\varnothing 7$		
MU 8	$\varnothing 8$	$\varnothing 9$		


(ONLY RUBBER)

MU8A, MU10A




(FITTING)

M5-1




(Suction cup with fitting)



VACUUM PAD	$\varnothing A$	$\varnothing B$	$\varnothing C$	L1	L2	L3
MU 8A	$\varnothing 8.2$	$\varnothing 8.8$	$\varnothing 5$	1	7	12
MU 10A	$\varnothing 10.4$	$\varnothing 11$	$\varnothing 6$	1.7	8	13


(ONLY RUBBER)

MU15



(FITTING)

M5-2



(Suction cup with fitting)

